

DO-02 series <DO•Temperature>

Portable Fluorescent DO meter



**Easy
maintenance
with Fluorescent
method**



- Auto temperature compensation, Auto pressure compensation, Manual salinity compensation are equipped as standard
- Easily viewable by large LCD display with backlight
- User-friendly by "Measuring stable mark" and "Auto lock function"
- Easy to carry around with carrying case

CEMCO

Easy maintenance with Fluorescent sensor. Most suitable for fish cultivation, aquarium, aeration tanks.

Model		 
DO	Measuring range	0-20.00 mg/L(ppm), 0-200.0%
	Resolution	0.01/0.1mg/L(ppm), 0.1/1%
	Accuracy	Either ± 2% measured value or ± 2% saturation, bigger value Either ± 2% measured value or ± 0.2mg/L, bigger value
	Response time	≤ 30sec (25°C, 90% response)
	Calibration point	Dissolved oxygen saturation 100% sample and 0% sample
	Temperature compensation	Auto, 0-50.0°C
	Pressure compensation	Auto, 60-120kPa
Temperature	Measuring range	0-50.0°C
	Resolution	0.1°C
	Accuracy	± 0.5°C
Other	Electric power source	AA battery x3 (1.5Vx3)
	IP	IP57 comparable
	Size and weight	Body: 88 x 170 x 33 mm / 313g Carrying case: 360 x 270 x 76 mm / 1.3kg
	Other	RoHS, CE, ISO9001:2008

Features

■ Fluorescent sensor

Advantage over Diaphragm type - Easy maintenance, low running cost, no effect from the water flow, no effect from the intergering substance.

■ Long operating life

Sensor life span is 8,000 hours.

■ Hold / Auto power off function

Hold function: Lock the measure value for recording

Auto power off function: Auto power off when no operation for 10 minutes

■ Large display

Large LCD would display DO value and temperature in one screen.



CEM CORPORATION

Head office: 1-10-25 Honkomagome, Bunkyo-ku, Tokyo 1138638
Phone: 81-3-3946-3335 Fax: 81-3-3946-0675

Overseas sales dept.: 1-10-25 Honkomagome, Bunkyo-ku, Tokyo 1138638
Phone: 81-3-3946-3201 Fax: 81-3-3946-3210

TAIWAN CEMCORPORATION: 3F, No.56, Sec.2, Jhongcheng Rd., Shilin District, Taipei 111, Taiwan
Phone: 886-2-2836-8603 Fax: 886-2-2832-1148

SHANGHAI CEMCORPORATION: 206 Floor A, 288 Yu Yao Lu Jingan Qu, Shanghai Shi
Phone: 86-21-6231-7631 Fax: 86-21-6230-9736

※ Specifications and appearance may change without prior notice due to improvements.

※ The actual color of the products may be slightly different from that shown in the brochure due to issues of color during printing.

For inquiry